

GETTING TO KNOW YOUR AUTOMATIC WATCH

This is an automatic watch equipped with a manual winding mechanism.

When the watch is worn on the wrist, the motion of the wearer's arm winds the mainspring of the watch.

If your watch has completely stopped, it is recommended that you manually wind the mainspring by turning the crown.



Slowly turn the crown clockwise (in the 12o'clock direction) to wind the

Continue to turn the crown until the mainspring is sufficiently wound. The second hand Set the time and date before putting the watch on your wrist.

HOW TO USE



Setting the time and date

It is good practice to make sure the hands are around the 5pm/am position before setting the date. Changing the date when the hands are between 9 and 3 could damage the movement of the watch.

The crown usually has three positions or settings that engage certain functions.

Position A: The normal operating position

Position B: The crown can be pulled out / unscrewed anti clockwise to unlock and wind the watch.

We recommend a minimum of 20 winds clockwise in order to engage the winding mechanism.

Position C or D (depending on your watch): When the crown is unscrewed / pulled out, turn the crown to set the desired date and time.

After completing the above, ensure the crown is screwed back down.

Your watch model number holds the key to understanding how your watch works.

For a full user guide of your watch, please refer to the manufacturer's website.

If you have any further questions get in touch:

Customer Services 01642 579957

